

Capabilities List for Wheels

MANUFACTURE	ASSEMBLY	PART	AIRCRAFT	MANUAL
AIRCRAFT BRAKING SYS	9543426	NOSE	FALCON	32-46-11
AIRCRAFT BRAKING SYS	9543809	MAIN	FALCON 20	32-41-45
AIRCRAFT BRAKING SYS	5004913-X	MAIN	LEAR 36	32-40-61
AIRCRAFT BRAKING SYS	5006450-1	NOSE	CANADAIR CL601	32-46-12
AIRCRAFT BRAKING SYS	5009029-1	MAIN	CANADAIR CL601	32-40-94
AIRCRAFT BRAKING SYS	9543991-X	MAIN	LEAR 24-25	32-40-35
AIRCRAFT BRAKING SYS	9544207-X	NOSE	LEAR	32-46-14
AIRCRAFT BRAKING SYS	AHA1290	NOSE	BOEING 737-300	32-42-55
B.F. GOODRICH	3-1070	NOSE	BOEING 727	32-40-01
B.F. GOODRICH	3-1306-X	MAIN	BOEING 727	32-40-21
B.F. GOODRICH	3-1395	NOSE	BOEING 727	32-40-01
B.F. GOODRICH	3-1414	MAIN	BOEING 727	32-40-21
B.F. GOODRICH	3-1439-X	MAIN	BOEING 737	32-40-31
B.F. GOODRICH	3-1479-X	MAIN	BOEING 747-400	32-45-02
B.F. GOODRICH	3-1484	MAIN	BOEING 737	32-45-03
B.F. GOODRICH	3-1559	NOSE	BOEING 737NG	32-40-51
B.F. GOODRICH	3-1674	MAIN	BOEING 737NG	32-42-28
B.F. GOODRICH	3-1597	MAIN	BOEING 747-400ERF	32-45-04
B.F. GOODRICH	3-1438-X	NOSE	BOEING 737	32-40-32
BENDIX/HONEYWELL	2604561-1	MAIN	BOEING 727	32-40-03
BENDIX/HONEYWELL	2606735-X	NOSE	BOEING 767-300	32-43-01
BENDIX/HONEYWELL	2609801-1	MAIN	BOEING 737	32-40-11
BENDIX/HONEYWELL	2607825-X	NOSE	BOEING 737	32-40-10
BENDIX/HONEYWELL	2606671-X	MAIN	BOEING 737	32-40-09
CLEVELAND WHEEL/BRAKE	40-148	MAIN	MU-2	MANUAL
CLEVELAND WHEEL/BRAKE	40-170	MAIN	BEECH	MANUAL
CLEVELAND WHEEL/BRAKE	40-204	NOSE	KING AIR	MANUAL
CLEVELAND WHEEL/BRAKE	40-289	MAIN	KING AIR	MANUAL
CLEVELAND WHEEL/BRAKE	40-77	NOSE	MU-2	MANUAL
CLEVELAND WHEEL/BRAKE	40-87F	NOSE	MU-2	MANUAL
MESSIER-BUGATTI-DOWTY	C20559100	MAIN	BOEING 777F	32-49-61
MESSIER-BUGATTI-DOWTY	C20562000	NOSE	BOEING 777F	32-49-62
MESSIER-BUGATTI-DOWTY	C20509000	MAIN	BOEING 767-300	32-49-51

Capabilities list for Brakes

MANUFACTURE	ASSEMBLY	AIRCRAFT	MANUAL
AIRCRAFT BRAKING SYS	5003096-X	LEAR 25	32-43-32
AIRCRAFT BRAKING SYS	9550504	FALCON 20	32-40-07
AIRCRAFT BRAKING SYS	5009027-5	CANADAIR CL601	32-44-74
B.F. GOODRICH	2-1147-X	BOEING 727	32-40-18
B.F. GOODRICH	2-1515-X	BOEING 747-400	32-46-02
B.F. GOODRICH	2-1566	BOEING 777	32-40-43
B.F. GOODRICH	2-1740-X	BOEING 737NG	32-42-27
B.F. GOODRICH	2-1628	BOEING 747-400ERF	32-46-06
B.F. GOODRICH	2-1474-X	BOEING 737	32-40-30
BENDIX/HONEYWELL	2606672-X	BOEING 737	32-40-08
MESSIER-BUGATTI-DOWTY	C20558000	BOEING 777F	32-49-60
MESSIER-BUGATTI-DOWTY	C20508000	BOEING 767-300	32-49-50